

Wired chronothermostat

WIRED CHRONOTHERMOSTAT code -REGOLO-CF



FEATURES

Digital chronothermostat code **-REGOLO-CF**, wired, which must be powered by the "Regolo" controller. Wall-mountable (flush-mounted), used to manage the temperatures of the various zones in the home by setting time slots for opening and closing the servomotors that will move the "Regolo" dampers to promote or prevent the passage of air. Can be used in REGOLO/REGOLO PLUS 2.0 systems to control servomotors of dampers installed on plenums combined with ducted units of various brands.

Hourly scheduling can be bypassed by forcing the manual closing or opening of each damper and changing the mode of operation to heating or cooling.

Main features of CF chronothermostat:

- Time setting and display;
- Display of the ambient temperature in which it is placed;
- Temperature setting;
- Manual operation mode (forced opening of the damper);
- Operation mode according to the set temperature set-point;
- Automated operation mode in time slots (weekly scheduling);
- Switching to cooling mode (for summer period) and heating mode (for winter period);
- Forced closure of dampers (shutdown).



Photo of the chronothermostat with plate (plate is not supplied)

Code	Description
-REGOLO-CF	Flush control digital chronothermostat